

ONE TRIP CHECKLIST



Don't forget...

- | | |
|--|---|
| <input type="checkbox"/> Underlayment* | <input type="checkbox"/> Undercut Saw |
| <input type="checkbox"/> Laminate Installation Kit | <input type="checkbox"/> Compound mitre saw |
| <input type="checkbox"/> Molding & Transitions | <input type="checkbox"/> Tape Measure |
| <input type="checkbox"/> Tapping block & pull bar | <input type="checkbox"/> Chalk line & chalk |
| <input type="checkbox"/> Eye Protection | |

* If using "attached back" laminate use the 6 mil moisture barricade

LAMINATE FLOORS

KNOW-HOW ■

- *The Flooring 1-2-3 book is a great resource for a flooring project*
- *Always purchase 10% extra flooring planks to allow for scrap*
- *Store the flooring planks in the room where it will be installed at least 48 hours prior to installation to acclimate the wood to the local humidity*
- *Make sure the subfloor is clean, free from dust, oil, wax or grease*
- *The underlayment overlaps should be adhered to create a single protective membrane*
- *If installing over concrete, check the water vapor emission. It may be necessary to use the 6 mil. Moisture Barricade for additional protection*
- *To improve appearance, plan your layout with planks running the length of the room*
- *Use 1/4 In. Installation spacers between the floor perimeter and wall to allow for the proper expansion space*

Learn More...

Videos, Step-by-steps, & Project Guides
[homedepot.com/knowhow](https://www.homedepot.com/knowhow)

More saving. More doing.™

