lay a garden path

Show guests the scenic route to your spa, gazebo or other backyard attraction with a stone and pea gravel garden path

Lay out path using garden hose. Stretch hose in desired route, marking grass with powdered chalk. Repeat for other border.

Use hoe to dig out borders of the path. Excavate sod and soil to 3 or 4 inches within pathway using square shovel. (For a more even path surface, use plate compactor to tamp earth down.)

Line path with landscape fabric, overlapping fabric edges 12 to 18 inches, if multiple pieces are used.

Pour bedding sand onto landscape fabric, to depth of about 2 inches. Rake smooth, taking care not to poke holes into fabric.

Place pavers down in desired formation. When sure of placement, settle into sand by tapping with mallet. Fill pathway around borders with pea gravel to grass line.

OPTIONS: The lack of edging is what gives this path its rustic look. For a more finished effect, install your pathway with brick, timer or concrete edging. Refer to The Home Depot Patios and Walkways 1-2-3 for how-to guides on this.



MATERIALS

- · Powdered chalk
- · Landscape fabric
- Bedding sand
- · Pea gravel

- Sandstone pavers
- Plate compactor (optional)
- Exterior paint

TOOLS

- · Garden hose
- Hoe
- · Square shovel
- Gravel rake
- Mallet

SKILL LEVEL

Beginner



Plate Compactor

may we suggest...

Do the job right by renting proquality tools from The Home Depot Tool Rental Center*, open seven days a week. A plate compactor is a garden project must-

have, as it effectively levels and compacts soil and/or gravel, preparing it for your DIY patio, pathway or any other project where a stable surface is critical to success.

*Not available in all areas. See store for details.