

HOW TO BUILD A LARGE URN CONTAINER FOUNTAIN



DIMENSIONS:
24' x 24' x 30'

SKILL LEVEL:
Beginner

ESTIMATED TIME:
3 - 4 hours

SPECIAL FEATURES:
Container Fountain Kit with LED Lights turns your planter into a glowing water feature

For this project, you will need:

- 30 in. H Stone Scalloped Rim Jar in Limestone
- TotalPond® Container Fountain Kit with LED Light
- Bosch 1-1/4 in. x 6 in. DareDevil Spade Bit
- Safety Eyewear
- Qty. 5 Oldcastle Holland 4 in. x 8 in. Concrete Overlay Harvest Blend Paver
- Qty. 6 Pavestone 7 in. x 7 in. Cafe RumbleStone Medium Wall Block
- Black Plastic Nursery Container
- 3 bags of Black Polished Pacific Pebble
- Protective gloves



1

Step 1

Drill a hole on the bottom of the planter that is 1 ¼ in. wide using the 1 ¼ in Drill Bit. TIP: Wear safety glasses when operating an electric tool



2

Step 2.

Assemble the TotalPond® Container Fountain Kit with Light and determine the height you'd like the water feature to sit. Be sure to estimate enough slack in the cord so you can position the pump in the center of the planter. TIP: mark on the cord the height.



3

Step 3.

Assemble the TotalPond® Container Fountain Kit with Light and determine the height you'd like the water feature to sit. Be sure to estimate enough slack in the cord so you can position the pump in the center of the planter. TIP: mark on the cord the height



4

Step 4.

Once epoxy has hardened, flip the planter over and add a small amount of water to test for leaks. For extra seal, we recommend reinforcing the seal with a caulk.

Step 5.

Once you are certain there is no leak, place the 5 smaller pavers under the planter. These will help will the cord running out the bottom. Once the planter is positioned, add the 6 pavers into the planter. Notice that your assembled TotalPond® Container Fountain Kit with Light is draped over the back of the planter.

Step 6 .

Position the TotalPond® Container Fountain Kit with Light on the pavers and begin to fill with water until the pump is fully submerged. We recommend covering the pavers inside the planter with a black planter or bucket to make them less visible

Step 7.

For a finishing touch, add the 3 bags or more of the black pebbles around the base of the planter.

Step 8.

Plug it in and enjoy!